




Typical Camera Blimp Setup



Use the slider to adjust the camera weight forward and aft to trim the blimp nose up. Fly the blimp nose up.



After the blimp is trimmed, place a piece of tape on the blimp under the slider to protect the blimp.



The Quick Disconnect is not included with camera balls or blimps